


### Inspektion lamp

Inspection lamp is used for the internal control of all types of extinguisher.



### Universal key

Universal key for opening all types of extinguisher.



### Special adaptor

for filling of portable fire extinguisher with an opening diameter up to 24 mm.

