

The AN-80 external antenna

This antenna is designed for Jablotron wireless products which use a frequency of 868 MHz and are equipped with a connector only for use with AN-8x antennas.

If the AN-80 antenna is used, the internal antenna in the device must be disconnected (see the wireless device's manual).

The active part of the antenna should be installed vertically and it should not be obstructed by any metal objects.


The antenna can only be placed on a non-conducting material.

If the antenna is used in an alarm system, it should be located in the area which is protected by the alarm system.

Note: Do not extend its RF cable.

Technical specifications:

<i>Communication band</i>	868 MHz
<i>Impedance</i>	50 Ω
<i>Cable length</i>	2m



Pod Skalkou 33
466 01 Jablonec nad Nisou

Tel.: 483 559 999
fax: 483 559 993
Internet: www.jablotron.cz