

The AN-81 external antenna

This antenna is designed for Jablotron wireless products, which use a frequency of 868 MHz and are equipped with a connector only for AN-8x antennas.

If you want to use the AN-81 antenna see the wireless device's manual for detailed instructions.


The active part of the antenna should be installed vertically and it should not be obstructed by any metal objects. If the antenna is not placed on a metal plate bigger than the antenna itself, then it is necessary to place a metal plate under the antenna nut (part of packaging). This metal profile can be fixed onto other metal objects or building constructions.

If the antenna is used in an alarm system, it should be located in the area which is protected by the alarm system.

Note: Do not extend its RF cable.

Technical specification:

| | |
|---------------------------|-------------|
| <i>Communication band</i> | 868 MHz |
| <i>Impedance</i> | 50 Ω |
| <i>Cable length</i> | 1.2m |



Jablotron s.r.o.
Pod Skalkou 33
466 01 Jablonec nad Nisou
Tel.: 483 559 911
fax: 483 559 993
Internet: www.jablotron.cz