


Specification Drawings



J R Industries Limited Whiting House Sir Alfred Owen Way Pontygwindy Industrial Estate Caerphilly CF83 2WH T: 029 2085 7630 F: 029 2085 7633



J R Industries Limited Whiting House Sir Alfred Owen Way Pontygwindy Industrial Estate Caerphilly CF83 2WH T: 029 2085 7630 F: 029 2085 7633



Page 1 - Roll type

ROBINSON SHUTTERS LIMITED

Registered Patent No. 144961

ROLL CLOSE GAP TYPE

FITTING INSTRUCTIONS

Users are reminded of their obligation to ensure that all persons involved in handling, installing, using or disposing of our products are made aware of these notes and that sufficient information is passed on to your customer to comply with the Act/1974.

In particular, note that in no circumstances should the vehicle to which the shutter is fitted be driven or be in motion at all with the shutter in the open position. A notice to this effect is printed on the identification plate and this should not be obscured by paint but be left clearly visible at all times.

A FITTING THE CHANNELS

- Mount the channels in the body to the measurement 'Width over channels' given on the label affixed to the channels. This will give a measurement %" (9mm) greater than the total width of the curtain over the nylon shoes.
- Ensure that the channels are securely fixed square to the structure, vertical and parallel to each other.
- 3) The Hanger Brackets/Pennant Plates are integral with the channels and <u>must</u> be secured at their top inboard edge, at 90° to the body structure. Check that the closure slide in each pennant plate moves freely in its slot.

B FITTING THE OPERATOR

- Detach the stop brackets from each end of the operator shaft they are only attached there for despatch purposes. See ----- C3.
- The spring drum is supplied pre-tensioned. The tension is held by a pin through the hub of the off side drum end cap. Do not remove this pin until the curtain is fitted. See ---- C4.
- Mount the operator in position by placing the flatted ends of the shaft in the 'U' pieces that are welded to the closure slides.

C FITTING THE CURTAIN

- Pass the curtain, Bottom Rail first, over the operator into the channels and lower
 it into the closed position.
 Note:- if necessary to facilitate passing the curtain beneath the header panel, the
 Finger Rail can readily be detached from the Bottom Rail and refitted when the
 curtain is in position.
- Attach the curtain to the operator, bolting through the slots in the top slat with the bolts already in position in the drum.
- 3) Bolt a stop bracket at each end of the Bottom Rail locating in the holes provided. These brackets arrest the curtain in the fully open position by coming into contact with the built-in stops at the top of the channels.
- Remove the pin from the off side drum end cap and the curtain is operational.

Page 2 - Roll type

D TENSION

- Should it be found necessary to either increase or decrease the spring tension, this
 is easily done without removing the curtain or the spring shaft, as follows;
- With the curtain in the 'Down' or 'Closed' position, replace the shaft locking pin in the off side drum end cap.
- Remove the screws securing the curtain to the drum.
- 4) With the aid of two ⁹/₁₆ " (26mm) open-ended spanners applied to the squared ends on the drum caps, hold the tension at one end and remove the locking pin. With a spanner at each end apply or release quarter turns to increase or decrease tension as required.
- 5) Replace the locking pin and re-attach the curtain to the drum,
- 6) Remove the locking pin and the shutter is operational.

E FASTENING

- Standard fastening is with Hasp and Staple. Normal practice is to fix the Hasp on the lower edge of the Bottom Rail of the shutter and the Staple on the body structure. But where specified or required, the Finger Rail can be fitted to the upper edge of the Bottom Rail to enable the Staple to be fitted on the Bottom Rail and the Hasp to the body structure.
- IMPORTANT: Under no circumstances must the Finger Rail be cut away to accommodate either the Hasp or Staple as this would have detrimental effect on the strength of the Bottom Rail.
- 3) When Transverse or Slam locks are specified the vertical channels have specially designed wearing pads embodied on the rear face which require recessing into the body pillars, but on no account must these be removed.

H LUBRICATION

- 1) Oil or grease should not be used in the shutter channels.
- 2) We recommend the use of CRC 5.56 as the best shutter lubricant.

SOLE DISTRIBUTOR FOR 'ROBINSON' SHUTTERS IN EUROPE IS:

Telex: 497634

Telephone: (0222) 549966

JACK ROBINSON SUPPLIES (CARDIFF) LTD.

Caxton Place, Pentwyn, Cardiff,

South Glamorgan CF2 7XN.